

HOW TO RE-INK TRODAT PREMIUM FLASH

RE-INKING MAXLIGHT **S**-STYLE AND **Z**-STYLE



1
Remove handle from the MaxLight mount by pulling upwards.



2
Select right colour of MaxLight re-fill ink and add a few drops in each ink port.



3
Put handle back onto mount. Let ink migrate overnight and test stamp. Repeat steps if necessary.

RE-INKING MAXLIGHT PRE-ASSEMBLED **Z**-STYLE



1
Slide die box out of MaxLight mount and place it on a piece of paper.



2
Select right colour of MaxLight re-fill ink and add a few of drops into slotted back of die box.



3
Let ink soak in and slide die box back into mount. Wait 45-60 minutes for ink to migrate and test stamp. Repeat steps if necessary.

RE-INKING PSI **E**-STYLE AND PRE-ASSEMBLED **Z**-STYLE



1
Slide die box out of PSI mount and place it on a piece of paper.



2
Select right colour of MaxLight re-fill ink and add a few of drops into the die box.



3
Let ink soak in and slide die box back into mount. Wait 45-60 minutes for ink to migrate and test stamp. Repeat steps if necessary.

RE-INKING SLIM STAMP **E**-STYLE AND PRE-ASSEMBLED **Z**-STYLE



1 Pull off the cover lens from Slim Stamp mount.*



2 Remove the index card.



3 Select right colour of MaxLight re-fill ink and add a few of drops into the cavities.



4 Let ink soak in and put index card and cover lens back in place. Wait 45-60 minutes for ink to migrate and test stamp. Repeat steps if necessary.

* Slim Stamp 1444, 2773, 3679, 4141 are re-inked like PSI stamps, just slide die box out of mount and add a few drops of ink.

RE-INKING SUPER SLIM



1 Pull off the cover lens from Super Slim mount.



2 Remove the index card.



3 Select right colour of MaxLight re-fill ink and add a few of drops into the cavities.



4 Let ink soak in and put index card and cover lens back in place. Wait 45-60 minutes for ink to migrate and test stamp. Repeat steps if necessary.

NUMBER OF RE-INKING DROPS (drops in total, not per port)

Maxlight (S-Style & Z-Style)

XL-55	6-8 drops
XL-75	6-8 drops
XL-115	8-12 drops
XL-125	8-12 drops
XL-145	8-12 drops
XL-165	16-20 drops
XL-185	12-16 drops
XL-225	24-28 drops
XL-245	20-24 drops
XL-265	12-16 drops
XL-275	25-30 drops
XL-700	40-46 drops
XL-720	18-24 drops
XL-750	30-40 drops
XL-800	45-55 drops
XL-495	14-16 drops
XL-535	16-20 drops
XL-655	20-24 drops

PSI & Slim Stamp (E-Style & Pre-Z-Style)

PSI 1919	4-6 drops
PSI 1444	8-10 drops
PSI 1479	10-12 drops
PSI 1854	10-12 drops
PSI 2264	12-15 drops
PSI 2773	12-15 drops
PSI 3255	12-15 drops
PSI 3679	15-20 drops
PSI 4141	12-15 drops

Super Slim

Super Slim 1442	4-6 drops
Super Slim 2054	8-10 drops
Super Slim 2564	10-12 drops